

Stock Breakout

Procedure

1

- Cut To Rough Length
- (Radial Arm Saw)



2

- Make A Reference Face
- (Jointer)



3

- Make A Reference Edge
- (Jointer)

4

- Plain To Rough Thickness
- (Thickness Planer)



5

- Rip Cut To Width
- (Table Saw - Rip Blade)



6

- Cross Cut To Length
- (Table Saw - Crosscut Blade)

7

- Sand To Final Thickness
- (Thickness Sander)

